

Startrite S-10 band saw, wood workshop. For use with wood only Access Level 3 (see Wood Workshop induction Guide on Access Levels) Continuous, wood-cutting band saw used to cut and shape a variety of hard and soft woods & wood-based board

 $\square$ 

 $\square$ 

 $\square$ 

 $\square$ 

 $\square$ 

Π

## **PPE Basic**

- Suitable Work coat (provided)
- Safety glasses or Faceshield, rated to BS/EN 166 (provided)
- Ear defenders/earplugs (provided)
- Keep rings, ties and dangling jewellery tucked away (or removed) or safe-keeping during cutting
- Stout footwear
- Keep hair tied back
- DO NOT wear gloves at this machine

## What to do before use

- CHECK machine isolator is in the OFF position
- VISUAL check of the machine for signs of damage to machine or electrical supply system
- IF STUDENT, report any faults to any member of workshop academic/ technical staff
- IFSTAFF, ensure correct blade type is fitted for the job before use parallel (along grain) or cross-cut (normal to grain)
- A BRIEF RUNNING CHECK of the fitted blade, i.e. under power watching & listening for reportable faults – is advised before use
- Fixed GUARDS fitted and in good condition?
- AREA AROUND the band saw is clean and tidy and free from obstructions?
  ADEQUATE overhead/natural/machine lighting?
- ADEQUATE overhead/natural/machine lighting?

Safety accessories suc	h as PUS	H STICKS ar	re present	and not	damaged
too badly?					

 Push sticks minimum SAFE RECOMMENDED length is 450mm from hand point to contact with blade teeth

How to	u Use This Band Saw	
	Refer to any OPERATING INSTRUCTIONS given during training or	
	timetabled workshops (if student or staff)	
	Ensure only 1 PERSON is OPERATING and IN CONTROL of the band	
-	saw. If a second person is 'assisting' with the take-off of long sections,	
	they must not pull the work through	
	Set blade GUARD to ONLY JUST clear work – or to clear machine fences	
	that may be fitted (parallel fence, for example)	
	Allow enough space between work and guard for good VISUAL awareness	
	of markings and cut lines.	
	Set cutting fences/guides BEFORE starting work	
	Switch ON LEV/Extraction System	
	ENABLE POWER to machine using isolator key-switch and/or ON	
	lever switch	
	Switch ON using START control button, and allow to run up to speed for	
	a few seconds before continuing	
	Place wood on bandsaw table in a STABLE position (i.e. non-rocking)	
	and ensure wood is not touching the running blade at startup	
- C.	Take a firm grip of the wood, ensuring (gloveless) fingers are NEVER	
	in-line with the blade	
	SLOWLY ease wood into blade, checking that the blade is cutting	
	efficiently and steadily through material before slowly allowing blade	
	to exit wood (to ensure that your fingers do not suddenly slip forward	
	into blade). Use a push stick if fingers are close to the blade in cut	
	direction.	
•	STOP machine using normal Stop button, not the Emergency Stop	$\Box$
	CLEAR wood and offcuts from the bandsaw table and place in a	
	suitable waste bin	$\Box$
	Use a hoover or portable extract machine to CLEAR WOOD DUST from	
	table and floor NEVER use sweep bruch/non or blow wood dust off surfaces - allow	
	NEVER use sweep brush/pan or blow wood dust off surfaces - allow	
	LEV to run for an additional minute after machining to pick up any residual dust	
	Isolate machine or switch to OFF	

